

SEAL REMOVAL AND INSTALLATION KIT



DESCRIPTION

Seal Removal Kit 15-Piece:

For the removal and fitting of oil seals without damaging the replacement seals or housing.

Universal Kit:

A range of adaptor sizes to fit majority of vehicles.

8 adaptors.

2 spacer adaptors.

2 screw threads.

2 seal removers.

PRECAUTIONS

Always wear safety gear.

Working in a clean and safe environment.

This task should be carried out by trained personnel.

Make sure to consult manufacturers manual.

Operating Instructions

Seal Removal Kit 15-Piece:

For the removal and fitting of oil seals without damaging the replacement seals or housing.

Universal Kit:

A range of adaptor sizes to fit majority of vehicles.

- **8 adaptors, sizes (inner x outer):** 36 x 46mm, 38 x 48mm, 40 x 50mm, 40 x 52mm, 42 x 54mm, 44 x 56mm, 46 x 58mm, 48 x 60mm.
- 2 spacer adaptors, sizes (L x diameter): 35 x 45mm, 65 x 45mm.
- 2 screw threads: M10 & M12, including washer and nut.
- Nut secured using 19mm socket or spanner (not supplied in the kit).
- 2 seal removers with different lengths and angles, superb for removing seals in tight confined spaces.
- Black phosphate finish.



Warranty

If you are unsure on how to use the item please contact us. If it were to fail due to a manufacturing fault or poor workmanship we will repair or replace it. Please contact your local dealer in the event you need to send the item back. You can also make a repair/replacement request on our website and download & complete the form online. Normal wear and tear along with misuse will void any warranty. Consumables are not covered under warranty.

www.welzh.com

